
Quick Start Guide for AEC.view Your customizable web portal

AEC.view



Homepage:

AEC.view provides a comprehensive suite for managing your connected assets, from fleet overview to detailed information on individual engines – in real time from everywhere.



1	
	//

Log in and customize your profile:


The initial login is done via the link provided in the registration email. Existing users select the following URL: <u>https://www.aec-view-zeppelin.com</u>. Password, language and time zone can be changed under "Profile" (bottom left).

2	ZEPPELIN [®] WE CREATE SOLUTIONS	Profile				
A	Home					
Ø	Мар	Profile				
ılı	Dashboard					
	Reports	User Account				
Ļ	Notifications	Name AEC User				
≣	Fleet table	E-mail zps-aec-user@zeppelin.com Organization				
0	Base data					
	Engine events	AEC Demo				
<u>+</u>	Data export	Notifications				
θ	Profile					
?	Documentation	 Receive notification for new reports uploaded Receive newsletter 				
∋	Logout					
<	Collapse menu	Select Language				



Tour of AEC.view:


Use the arrow button to collapse and expand the asset list.



5	
5	
J	

Map view:


In the map view, you will find the sites of the assets and also POIs. (Use the buttons for zooming in/out, location details and instant updating. You can also switch between different map views, e.g., satellite or standard map view).



14	Ļ
	ſロ

Dashboard:


Detailed view of individual assets: Status information, site, power on/off of the engine and connectivity hardware, operating hours, technical information, oil analyses (optional), maintenance information (optional), history of the measured values (up to 30 days the time frame can be adjusted via the drop-down menu).



Г		
L		
C	J	

Status report:


Monthly PDF status reports including engine load, operating hours and fuel consumption.





Fleet overview:


This view allows you to compare measured values across multiple assets or the entire fleet. Add columns for relevant information from the list of available measuring points.



7.

Notifications (alerts):

Set up automatic SMS and e-mail alerts for existing measurement points, e.g. On-board electrical system voltage < 23.9V. Define settings for trigger interval and escalation interval. Several measuring points with individual tresholds can be combined.





Engine messages:

Overview of engine events with some more details.

•

ZEPPELIN* WE CREATE SOLUTIONS Home

- 🚺 Мар
- Dashboard
- Reports
- Notifications

- Base data
- Engine events

Fleet table

- Data exportProfile
- Documentation
- → Logout

Q Search

- ✓ Favorites ★
 - 💿 🊊 Vessel A 🛨
 - 💿 🊊 Vessel B ★
- 🂿 🊊 Vessel C ★
- ✓ All
- Aggregat 1
- Aggregat 2
- Baumaschine
- 💿 🛱 Lokomotive
- 🍥 🏯 Vessel A ★

🊊 Vessel B ★

💿 🊊 Vessel C ★

۲

ADD GROUP

EDIT

3

7

Engine events > All > Vessel A

Vessel A *

▼

Asset	Running hours	Measure ID	Measure	Description	Severity	Event Time
Engine 1	10575.7 h	518	Switch Input #5	Value Above Setpoint	SHUTDOWN	01.01.2024 16:27:32
Engine 1	10575.7 h	518	Switch Input #5	Value Above Setpoint	ALARM	01.01.2024 16:27:32
Engine 1	10575.8 h	519	Switch Input #6	Value Above Setpoint	ALARM	01.01.2024 16:27:32
Engine 1	10575.8 h	519	Switch Input #6	Value Above Setpoint	SHUTDOWN	01.01.2024 16:27:32
Engine 1	10575.5 h	4609	Engine Start Failed	No Details	SHUTDOWN	01.01.2024 16:27:32
Engine 1	10896.25 h	1552	Input Voltage	Value Below Setpoint	ALARM	29.12.2023 01:38:18


Q Search

< Collapse menu

\bigcirc	
G	
J J	

Data export for data analysis and use in other applications:


Export your data from the AEC.view to other applications for further data analysis.



10.

Service:

Overview of oil sample evaluations and maintenance history as well as optional maintenance planning depending on the subscription level.



Our service helpdesk team is available at any time for further assistance. Simply contact us at <u>zps-foc-helpdesk@zeppelin.com</u>

2

or call the support hotline at 0800 589 27 87 (from abroad: +49 40 853 151-222).